G100



APPROVED FLOORING TYPES	LVT • LVP • WPC •	
DESCRIPTION	When it comes to ultimate adaptability to numerous flooring types, G100 holds the market. Breaking all the rules, this revolutionary product saves time with its instant access to light traffic. G100 provides the waterproof benefits of a hard-set adhesive while aggressively retaining PSA-like sur	
APPROVED SUBSTRATES & SURFACES	 APA underlayment grade plywood and OSB Association grade particleboard Concrete and radiant heated subfloors that do not exceed 85°F (30°C) Cement backer board Existing well-bonded non-cushion-backed vinyl, tile and sheet flooring Fully secured cork underlayments Gypsum and lightweight concrete (primed with universal primer) Terrazzo (properly prepared with all waxes and surface finishes removed) 	
SUBSTRATE TESTING	RH - 95% [ASTM F2170] pH - 5-12 MVER - 12 lbs [ASTM F1869]	
SUBSTRATE & SURFACE PREPARATION	 Follow flooring manufacturer's guidelines for allowable levels of moisture. Substrate must be prepared per ASTM F710 standards including, but not limited to the following: Concrete floors must be dry, clean, smooth and structurally sound. They shall be free of any foreign materials that might prevent adhesive bond, including dust, dirt, solvent, paint, wax, oil, grease, residual adhesive, adhesive removers, incompatible sealers, fire-retardant chemicals, fungicides, release agents, alkaline salts, excessive carbonation, laitance, mold, mildew, and curing, sealing, hardening or parting compounds. Fill all surface cracks, grooves, depressions, control joints and non-moving joints with moisture-resistant patching and self-leveling compounds, allow to fully cure and correct high spots before applying adhesive. The substrate, adhesive and flooring must be acclimated in an enclosed building with the HVAC operational between 60-95°F (15-35°C), and between 30-65% relative humidity, for at least 72 hours before, during and after the installation. When installing over radiant heated subfloors, turn the heat off for 24 hours before, during and after installation. Failure to turn the heat off may result in shortened working time of the adhesive. When turning radiant heat back on, raise it incrementally, not to exceed a change of more than 5 degrees per hour to a maximum of 85°. 	
	 PRECAUTIONARY NOTES: Concrete must be placed in strict accordance with applicable standards and specifications. An intact moisture vapor retarder must be present below the concrete (see ASTM E1745), must be fully cured (at least 45 days) and without hydrostatic pressure. Although G100 is a high-moisture tolerant adhesive, it does not form a moisture vapor barrier and will not protect flooring from moisture damage. 	

protect flooring from moisture damage.Flooring must be acclimated per manufacturer's guidelines.



G100



APPLICATION INSTRUCTIONS

Follow flooring manufacturer's guidelines for layout, design and any special precautions for installation. 1. Spread adhesive using required tools (see tool chart below).

- 2. Install flooring per the instructions below dependent upon desired application method.
 - PSA (porous and non-porous substrates)
 - Wait 30-60 minutes after adhesive is spread to allow it to dry (adhesive will darken to visually cue installer).
 - Working time is approximately 12 hours under acceptable temperature and humidity conditions.
 - Semi-wet set (porous substrates only)
 - Wait 20-30 minutes after adhesive is spread to allow it to skin over.
 - Working time is approximately 20-30 minutes under acceptable temperature and humidity conditions.
- 3. Roll and cross roll floor with a 75-100 lbs (34-45 kg) roller at the end of the installation to ensure proper transfer of adhesive.

PRECAUTIONARY NOTES:

- Do not wet mop the floor for 72 hours after the install is complete.
- Do not strip and finish the floor for 72 hours after the install is complete.
- Reseal lid when not in use to protect product.

REQUIRED TOOLS AND COVERAGE

*Trowel dimensions are width X depth X spacing. Coverage is approximate and may vary depending on porosity of substrate and the angle at which the trowel is held.

Flooring Type	Tool* (images not to scale)		Estimated Coverage
Porous: LVT, LVP, WPC,	1/16" x 1/16" x 1/16" (1.6mm x 1.6mm x 1.6mm) Sq Notch		150-180 sf/gal
Non-porous: LVT, LVP	1/16" x 1/32" x 1/32" (1.6mm x .8mm x .8mm) U Notch		220-260 sf/gal

It is the sole responsibility of the contractor/installer to determine the proper porosity of the subfloor, apply the proper amount of adhesive for the job conditions and ensure that all instructions, procedures and practices are strictly adhered to.

CLEANING INSTRUCTIONS

While product is still wet: use a damp cloth and water to remove.

While product is still soft: use adhesive remover/stripper, denatured alcohol or mineral spirits. Always check compatibility on a piece of scrap flooring.

See next page for Product Characteristics



G100



	Product Identification	Transitional Pressure Sensitive Adhesive	
CHARACTERISTICS	Base Chemistry	Hybrid acrylic	
	Curing Method	Proprietary modified cross-linking	
	Appearance	Mint green (wet), Dark green/teal (dry)	
	Consistency	Smooth, medium viscosity liquid	
	Application	Easy troweling or roller applied Non-flammable	
	Flammability		
	Freeze/Thaw	Stable to 10°F (-12°C)	
	Shelf Life	2 years	
MOISTURE	Moisture Control	N/A	
	RH	95%	
	рН	5-12	
	MVER	12 lbs	
ΠΜΕ	Open Time	20-30 min (semi-wet set)	
	Dry Time	30-60 (PSA)	
	Working Time	12 hrs (PSA), 20-30 min (semi-wet set)	
	Cure Time	12 hrs	
	Pot Life	N/A	
TRAFFIC	Light Traffic	0 min (PSA) 12 hrs (semi-wet set)	
	Heavy Traffic	24 hrs	
	Heavy Rolling Loads	48 hrs	
SUSTAINABILITY	Solvents	None	
	Isocyanates	None	
	VOC (g/L) - SCAQMD Rule#1168	11	
	LEED Points	Contributes to low emitting materials	
	Certifications	N/A	
ACOUSTICS	IIC (Delta)	N/A	
	STC (Delta)	N/A	

INFORMATION

info@raskinind.com.



To Market Global | 710 Powerline Road, Suite G | Deerfield Beach, FL 33442 www.raskinind.com | 1-561-997-6658